

HARDWARE LIST	CODE	PARTS	QTY.
	1	ВАСК	1
	2	SEAT	1
	3	ARM	2

	CODE	PARTS	QTY.
RE LIS.	A	M8x45MM 🕪 0	9
ARDWARE	В	ALLEN KEY	1
НА			,

⚠ Note:

Do not tighten the screws at one time.

Tighten each screw to half the depth, and then tighten one by one after fixing the position