


Assembly Instruction





Dining Chairs







ASSEMBLY TIPS:



1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Parts List



Number	Name	Part	Qty
1	Seat		x1PC
2	Front Leg		x2PC
3	Back Leg		x2PC
4	Metal rings		x1PC

Number	Hardware	Part	Qty
A	M6*25mm		x17+1EXT
B	Washer		x17+1EXT
C	Allen Wrench		x1PC
D	Foot		x4+1EXT

1




2




3

Ensure that each screw is tightened.



Rotate it to ensure the chair is flat on the floor !



Additional Note About Safety: Bolts may loosen during normal everyday use. They should be periodically inspected and tightened to prevent damage or injury. Always check to be sure that all hardware is kept tightened. Thank you for your purchase.